



Technical data sheet

## BUBI LF Adhesive Primer

BUBI LF Bonding Primer is a quality, solvent-free primer for preparation of the substrate to optimize the adhesive properties of acrylate, butyl and bitumen- rubber adhesive tapes. It can be used on all absorbent, mineral substrates e.g. concrete, cement plaster, cellular concrete, brickwork and sand-lime bricks that are finished flush. Application is also possible on polystyrene panels. BUBI LF Primer is self- adhesive and resistant against humidity and warm temperatures.

### ADVANTAGES

- a stronger primer coat
- forms an adhesive film, self- adhesive

### RECOMMENDED PRODUCTS



AIRSTOP Applicator roller

### AVAILABLE DIMENSIONS

Article number	Packing unit	Content - kg	Carton content
3BUBILF	Dosing bottle	1 kg	6 pieces
3BUBILF5	Pot	5 kg	

### TECHNICAL DATA

<b>Material composition</b>	water- based acrylate polymer dispersion	<b>Working temperature</b>	-5–35 °C
<b>Film characteristics permanently</b>	elastic	<b>Drying time</b>	15 - 40 min
<b>Coverage</b>	10 m <sup>2</sup> /kg	<b>Colour</b>	White
<b>Storage</b>	12 months in closed can, dry, closed ; + 15 °C - + 25 °C , without sun, the product is not frost-resistant!		

ISOCELL GmbH & Co KG  
Gewerbstraße 9  
5202 NEUMARKT AM  
WALLERSEE | Österreich  
Tel.: +43 6216 4108  
office@isocell.at

ISOCELL FRANCE  
170 Rue Jean Monnet | ZAC de  
Prat Pip Sud  
29490 GUIPAVAS | France  
Tél.: +33 2 98 42 11 00  
contact@isocell-france.fr

ISOCELL Sverige AB  
Torshamnsgatan 35  
164 40 KISTA | Sverige  
Tel.: +46 10 130 25 00  
info@isocell.se

ISOCELL SCHWEIZ AG  
Herbergstrasse 29  
9524 ZUZWIL | Suisse  
/Schweiz  
Tel.: +41 71 940 06 72  
office@isocell.ch

ISOCELL BUREEL BELGIË  
Außenborner Weg 1 | Schoppen  
4770 AMEL | Belgique  
Tel.: +32 80 39 90 58  
office@isocell.be

**ISOCELL**

WWW.ISOCELL.COM

# BUBI LF Adhesive Primer

## APPLICATION

Stir BUBI LF Bonding Primer well, then spread evenly using a roller or a brush (apply twice to porous surfaces) and allow to dry. Be sure to apply evenly!  
Before applying the adhesive tape the Primer should be dried to transparency. Thick Primer can be thinned by adding water.  
The substrate must be level, firm, dry and free from grease, oil and dust.

